

## COPERTURA RACCORDI INFERIORE

Questa istruzione è parte integrante del libretto dell'apparecchio sul quale viene installato l'accessorio.

A tale libretto si rimanda per le AVVERTENZE GENERALI e per le REGOLE FONDAMENTALI DI SICUREZZA.

**⚠** Prima di effettuare qualsiasi operazione togliere l'alimentazione elettrica all'apparecchio.

**⚠** Questo accessorio deve essere installato solo da personale professionalmente qualificato.

### Il kit è composto da

	Q.tà
1 Copertura inferiore	1
2 Supporto magnete sx	1
3 Supporto magnete dx	1
4 Ventosa magnetica	2
5 Vite autoformante 3 x 12 (A)	1
6 Vite autoformante 3.5 x 12 (B)	1
7 Foglio istruzioni	1

## HYDRAULIC CONNECTION COVER

These instructions are an integral part of the installer manual on which the accessory is installed.

See the manual for the GENERAL WARNINGS, GENERAL SAFETY DEVICES.

**⚠** Before carrying out any operation, first disconnect the electric power supply to the boiler.

**⚠** The accessory must be installed by professional qualified personnel.

### The kit is composed of

	Q.ty
1 Lower hydraulic cover	1
2 Left magnet holder	1
3 Right magnet holder	1
4 Magnetic suction cup	2
5 3 x 12 self tapping screw (A)	1
6 3.5 x 12 self tapping screw (B)	1
7 Instructions sheet	1



